

Converter plate for electronic gang box

DWC-GPLT	DWC-GPLT-W





WHAT'S IN THE BOX					
Option A Installation Screws	(A)	4	Camera Mounting Screws		4
Option B Installation Screws	389 389	2			

NOTE: Download all your support materials and tools in one place.


- 1. Go to: http://www.digital-watchdog.com/resources
- 2. Search your product by entering the part number in the **'Search by Product'** search bar. Results for applicable part numbers will populate automatically based on the part number you enter.
- 3. Click **'Search'**. All supported materials, including manuals and quick start guide (QSGs) will appear in the results.





Quick Start Guide

PRODUCT OVERVIEW




INSTALLATION

Connect the converter plate to the electric gang box.


Use the 4 screws (A) included with the converter plate when using a 2-gang handy electrical box.

- Use the 2 screws (B) included with the converter plate when using a switch box or a 1-gang handy electrical box.
- Pass wires through and make the connections.
 - Use the CABLE-OUT spaces in the converter plate.
- Sollow the table below to connect the camera to the appropriate holes.
- 4 Mount the camera to the upper side of the converter plate to complete the installation.

A. 2-gang handy electrical box



B. 1-gang handy electrical box and Switch Boxes



Mounting holes	Compatible cameras
Mounting holes labeled 1	V4, MV4, V6 vandal dome cameras
Mounting holes labeled 2,	MF, MV8, MVD8, PVF, MVC8 low-profile vandal
2#	dome cameras
Mounting holes labeled 4	VA, MVA, MV7, D4 vandal dome and ball cameras
Mounting holes labeled 5	D3, MD7 indoor dome cameras
Mounting holes labeled 6	MD4 indoor dome cameras