







WHAT'S IN THE BOX					
Hegaxonal Wrench (HEX2.0)		1 Set	Template sheet	•	1 Set
Screw and plastic anchor-2pcs		1 Set	Quick Setup Guide		1 Set
DC plug cable		1			

NOTE: Download all your support materials and tools in one place

- 1. Go to: http://www.digital-watchdog.com/resources
- Search your product by entering the part number in the 'Search by Product' search bar. Results for applicable part numbers will populate automatically based on the part number you enter.
- Click 'Search'. All supported materials, including manuals and quick start guide (QSGs) will appear in the results.



Attention: This document is intended to serve as a quick reference for initial set-up. It is recommended that the user read the entire instruction manual for complete and proper installation and usage.

Tel: +1 (866) 446-3595 / (813) 888-9555


digital-watchdog.com

Technical Support Hours: 9:00AM - 8:00PM EST, Monday thru Friday



### STEP 1 - PREPARING TO MOUNT THE CAMERA

- 1. The mounting surface must withstand five times the camera weight.
- 2. Do not let the cables get caught in improper places or the electric line cover can be damaged. This may cause a short or fire.
- 3. Use the mounting template to mark and drill the necessary holes in the mounting surface.
- 3. This product is intended to be supplied by a UL Listed Power Supply Unit marked "Class 2" or "LPS" or "PS2" and rated 12 Vdc, 0.36A min.



## STEP 2 - CABLING THE CAMERA TO

**EXTERNAL DEVICES** 

Pass the wires through the mount bracket and make all necessary connections. Connect the BNC cable and power cables to the camera.

**Quick Start Guide** 

Power Requirements	Power Consumption
DC12V	DC12V (LED off): 1.89W, 157mA DC12V (LED on): 4.26W, 355mA



# STEP 3 - CHANGING THE SIGNAL IN THE CAMERA

- The camera supports HD-Analog, HD-CVI and HD-TVI signals. To switch between the signals:
  - a. Enter the camera's OSD menu from a recorder supporting UTC communication. Go to SETUP > OUTPUT > ANALOG MODE.
  - b. Set the camera's analog signal output from the following options:
  - HD-A: supports 5MP/1944p @ 20fps 4MP/1440p @ 30fps, 2.1MP/1080p @ 30fps and 720p @ 30fps.
  - HD-T: supports 5MP/1944p @ 20fps, 4MP/1440p @ 30fps, 2.1MP/1080p @ 30fps and 720p @ 30fps.
  - HD-C: supports 4MP/1440p @ 30fps, 2.1MP/1080p @ 30fps and 720p @ 30fps.
  - CVBS: supports up to 960H @ 30fps
  - c. Change CONFIRM to ON to save the changes.
  - d. Go to the EXIT menu and select SAVE&EXIT to save all changes. The camera signal automatically.

### OUTPUT

NOTE: To use your Star-Light Plus™ 5MP cameras at a lower resolution, you must use a VMAX® A1 Plus™ DVR to access the camera's menu due to the cameras being set to 5MP as the default. A DVR that does not support 5MP resolution may recognize the camera, but will not deliver a picture

### STEP 4 - INSTALLING THE CAMERA


- 1. Once all cables have been connected, use the screws included with the camera to properly mount and secure the camera to the mounting surface.
- 2. Adjust the camera's pan, tilt and position to achieve the desired view. The cameras' max angles are:

Pan: 0° ~ 360°

Tilt: 0° ~ 90°

Rotation: 0° ~ 360°

3. Once the installation is complete, tighten the pan/tilt/rotation screw until it's secure.



Titling 90°